

# DREAME


## User Manual

Model:C011  
Dreame Light Bulb L11

### Important Safety Guidelines

- For indoor use only** – Avoid humid environments.
- Child Safety Advisory** – Not for unsupervised use by children.
- Keep away from Heat & Flammables** – Install away from heat sources and flammable materials.
- High Temperature Warning** – The bulb heats up during operation. Avoid touching during or after use.
- Dimmer Incompatible** – External dimmers may cause malfunctions.
- Operating Temperature:** -10°C to +40°C.
- Not for Emergency Use** – Do not install in emergency exit fixtures.
- Do Not Use if Damaged** – Replace if the outer lamp envelope is cracked or broken.
- LED Technology** – Unlike halogen lamps, this bulb does not require a protective barrier and is suitable for open luminaires.
- Glare Advisory** – Do not stare directly at the bulb for extended periods.
- Electric Shock Hazard Warning** - Do Not Touch Live Parts with Wet Hands.

### At a Glance:



### Installation Instructions

- Ensure the bulb holder is powered off before installation.
  - ROTATE CLOCKWISE until snug (do not overtighten).
- 
- When the bulb is ready to be removed after a period of use, please turn off the power to the bulb holder/socket and wait for a few minutes to avoid burns.

### Status description:

- Matter Pairing Mode** – First Power-On Flashes red for 2 seconds, indicating that the device is in Matter Pairing Mode.
- Dreamehome APP Pairing Mode** – Repeat the on/off cycle three times (turning off only after the light has come on, turn off for one second each time), then turn on the bulb. The bulb will flash a red light effect for 2 seconds, followed by a blue light for 2 seconds, indicating that the device is in Dreamehome APP pairing mode.
- Factory Reset** – Repeat the on/off cycle six times (turning off only after the light has come on, turn off for one second each time). The bulb will enter the reset state. During the reset process, the device will continuously flash red, green, and blue lights. After a successful reset, the device will flash a red light for 2 seconds, then execute the default lighting effect.
- Tip** – Resetting will erase all existing data on the device

### Connecting to the Dreamehome APP

#### Requirements:

- 2.4GHz Wi-Fi router (5GHz Wi-Fi not supported).
- iOS 12.0+ or Android 6.0+ device.

#### Requirements:

- Download Dreamehome APP (Apple Store/Google Play).



- Open Dreamehome APP and Enable phone Bluetooth.
- Click the upper right corner to add a device.
- Scan the QR code below or manually select to add a device.



- Follow the on-screen instructions to complete the connection.

### Matter Connection Guide

#### Requirements:

- Matter-compatible hub (e.g., Apple HomePod, Amazon Echo).
- Matter-supported app (e.g., Apple Home, Amazon Alexa).
- IPv6 network.
- iOS 16.1+

### Steps:

- Enable Bluetooth on your phone.
- Power on the bulb (red flash confirms readiness). If no flash, cycle power three times.
- Locate the Matter QR code (manual, bulb base, or Dreamehome APP settings).
- Power on the Matter-enabled smart home hub, such as Apple HomePod.
- Open your Matter app, scan the QR code, and follow prompts.

### Alexa/Google Assistant Setup

- Open the Alexa/Google assistant app and connect the device.
- Click 'Alexa/Google assistant user guide' and follow the instructions to complete the settings.

### Troubleshooting (FAQ)

#### 1. Dreamehome APP Connection Issues

- Confirm power and Bluetooth are on.
- Ensure the bulb flashes blue for 2 seconds at this time. (Dreamehome APP pairing mode).
- Confirm use 2.4GHz Wi-Fi and correct credentials.
- Keep the bulb close to the phone during setup.

#### 2. Matter Connection Failure

- Confirm whether the bulb is flashing red for 2 seconds at this time.
- Perform a factory reset – Repeat the on/off cycle six times (keep the power off for 1 second, and perform power off after the light opening). The bulb will enter the reset state. During the reset process, the device will continuously flash red, green, and blue lights. After a successful reset, the device will flash a red light for 2 seconds, then execute the default lighting effect.

### 3. Disconnected Bulb

- Check power and network stability.
- Re-pair the device via the app if needed.

### Specifications

- Voltage: AC 100-240V
- Power: 8.5W
- Brightness: 800 lumens

### Customer Support

- Manufacturer: Dreame Trading (Tianjin) Co., Ltd.
- Address: Room 2112-1-1, South District, Finance and Trade Center, No. 6975 Yazhou Road, Dongjiang Bonded Port Area, Tianjin Pilot Free Trade Zone, Tianjin, China
- Warranty: 12-month limited warranty
- Support: Lifetime technical support
- Email: supportus@dreame.tech
- Website: www.dreame.tech

### ⚠ Notice for all

AC supply

DOUBLE INSULATION

### Important Safety Instructions

Do not allow children to assemble or install this product. Avoid installing this product near large heat sources or other dangerous sources. Do not use the device in the environment at too high or too low temperature, never expose the device under strong sunshine or too wet environment. The suitable temperature for the device and accessories is -10°C to 40°C. Unless specifically indicated that it is safe to do so in the user guide or

instruction manual, do not use this device in an environment that exceeds the recommended low or high temperature. When supplying, please place the device in an environment that has a normal room temperature and good ventilation.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS CAUTION – RISK OF ELECTRIC SHOCK. Do not use if outer lamp envelope is damaged or broken.

This lamp employs light emitting diode technology and unlike tungsten-halogen lamps does not require a barrier. Lamp is suitable for open luminaires.

### FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

### FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party

Company Name: ANTEK SERVICE INC  
Address: 901 N PENNSYLVANIA ST STE O DENVER, CO 80203 Unite States  
Telephone: +01303-8006306

### ISED Compliance Statements

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et  
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-005.

Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

### IC RF Statement:

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.